




Safety Indicator

Component Location index

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS section (24) before performing repairs or service.

SAFETY INDICATOR (In the gauge assembly)

- Removal, page 23-129 ('93-'96) ('91-'92)
- Troubleshooting, page 23-152 ('94-'96) ('91-'93)
- Input Test, page 23-150 ('94-'96) ('93) ('91-'92)



*1: NSX-T (open top) only

Description

Safety Indicator System:

LED's are used to indicate when the trunk lid, engine compartment lid, a door, or the roof is not latched, or when a brake light is faulty, or when the roof is not stored or improperly stored in its holder. The LED's will go on and stay on for about two seconds after the ignition switch has been turned ON, to show that the system circuit is functioning.

Brake Light Bulb Failure Indicator:

If all brake light bulbs are OK, the indicator light stays off because the ORN/WHT wire is grounded by the two brake light failure sensors connected in series. With the brake lights off, the ground is provided through the diode, the failure sensor relay coil, and bulb filaments. With the brake light on, all four relays (two in the left sensor, two in the right sensor), connected in series, supply ground. If any of the four bulbs is not working, the chain is broken and the ORN/WHT wire is not longer grounded. The indicator light comes on.