

# Integrated Control Unit

## Input Test


SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section 24](#) before performing repairs or service.



Remove the left kick panel cover, and the relay holder from its bracket, then disconnect the 16-P connector from the integrated control unit. Remove the integrated control unit from the under-dash fuse box.

Inspect the connector and socket terminals to be sure they are all making good contact.

- If the terminals are bent, loose, or corroded, repair them as necessary, and recheck the system.
- If the terminals look OK, make the following input tests at the connector.
  - If any test indicates a problem, find and correct the cause, then recheck the system.
  - If all the input tests prove OK, the control unit must be faulty; replace it.

NOTE: Different wires with the same color have been given a number suffix to distinguish them (for example, YEL<sup>1</sup> and YEL<sup>2</sup> are not the same).





View from wire side

**Entry Light Timer System:**

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 34 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
3	WHT/BLK	Under all conditions	Attach to ground: Ignition key light and foot well lights should come on.	<ul style="list-style-type: none"> <li>• Blown bulb or No. 34 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
4	GRN/BLU <sup>2</sup>	Driver's door open	Check for voltage to ground: There should be 1 V or less.	<ul style="list-style-type: none"> <li>• Faulty driver's door switch</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>



**Key-in Reminder System:**

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 34 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
3	GRN/BLU <sup>2</sup>	Driver's door open	Check for voltage to ground: There should be 1 V or less.	<ul style="list-style-type: none"> <li>• Faulty driver's door switch</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
4	BLU/GRN	Ignition key is inserted all the way into the ignition switch	Check for voltage to ground: There should be 1 V or less.	<ul style="list-style-type: none"> <li>• Faulty ignition key switch</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>

(cont'd)

# Integrated Control Unit

## Input Test (cont'd)



View from wire side

### Lights-on Reminder System:

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 34 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
3	A5	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 5 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
4	GRN/BLU <sup>2</sup>	Driver's door open	Check for voltage to ground: There should be 1 V or less.	<ul style="list-style-type: none"> <li>• Faulty driver's door switch</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
5	A6	Headlight switch ON	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 38 (15 A) fuse</li> <li>• Faulty Headlight switch</li> <li>• Faulty taillight relay</li> <li>• An open in the wire</li> </ul>
6	ORN	Connect the A9 terminal to the ORN terminal	Check chime operation: Chime should activate each time the battery is connected.	<ul style="list-style-type: none"> <li>• Faulty chime</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>

### Seat Belt Reminder System:

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 34 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
3	A5	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 5 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
4	A13	Ignition switch ON (II) and driver's seat belt not buckled	Check for voltage to ground: There should be 1 V or less.	<ul style="list-style-type: none"> <li>• Faulty seat belt switch</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>



**Rear Window Defogger Timer System:**

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 34 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
3	A5	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 5 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
4	WHT/RED	Defogger switch pushed	Check for continuity to ground: There should be continuity as the switch is pushed.	<ul style="list-style-type: none"> <li>• Faulty defogger switch</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
5	A10	Ignition switch ON (II)	Attach to ground: The rear window defogger should work and the defogger switch indicator light should come on.	<ul style="list-style-type: none"> <li>• Blown No. 4 (15 A) fuse</li> <li>• Faulty defogger relay</li> <li>• Blown bulb</li> <li>• An open in the wire</li> </ul>



**Oil Pressure Indicator System:**

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 34 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
3	A5	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 5 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
4	WHT/BLU <sup>2</sup>	Engine running	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Faulty charging system</li> <li>• An open in the wire</li> </ul>
5	YEL/RED	Ignition switch OFF	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Faulty engine oil pressure switch</li> <li>• An open in the wire</li> </ul>
		Ignition switch ON (II)	Check indicator light operation. If the light does not come on, attach the YEL/RED terminal to ground: The light should come on as the ignition switch is turned ON (II).	<ul style="list-style-type: none"> <li>• Blown bulb</li> <li>• An open in the wire</li> </ul>
		Start the engine	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Insufficient oil</li> <li>• Improper lubrication</li> <li>• Faulty engine oil pressure switch</li> </ul>

(cont'd)

# Integrated Control Unit

## Input Test (cont'd)




### Side Marker Light Flasher System:

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>Poor ground (G401, G402, G403)</li> <li>An open in the wire</li> </ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>Blown No. 34 (15 A) fuse</li> <li>An open in the wire</li> </ul>
3	A5	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>Blown No. 5 (15 A) fuse</li> <li>An open in the wire</li> </ul>
4	A6	Headlight switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>Blown No. 38 (15 A) fuse</li> <li>Faulty headlight switch</li> <li>Faulty taillight relay</li> <li>An open in the wire</li> </ul>
5	A11	Ignition switch ON (II) and turn signal switch in left position	Check for voltage to ground: It should change from 0 – 12 – 0 V repeatedly.	<ul style="list-style-type: none"> <li>Blown No. 46 (10 A) fuse</li> <li>Faulty turn signal/hazard relay</li> <li>An open in the wire</li> </ul>
6	A3	Ignition switch ON (II) and turn signal switch in right position		
7	PNK/BLU	Connect the A9 terminal to the PNK/BLU (or BLU/WHT¹) terminal.	Check the front side marker lights: The left (or right) front side marker light should come on as the battery is connected.	<ul style="list-style-type: none"> <li>Blown bulb</li> <li>Poor ground (G301)</li> <li>An open in the wire</li> </ul>
8	BLU/WHT¹			

### Power Window Key-off Timer System:

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>Poor ground (G401, G402, G403)</li> <li>An open in the wire</li> </ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>Blown No. 34 (15 A) fuse</li> <li>An open in the wire</li> </ul>
3	A5	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>Blown No. 5 (15 A) fuse</li> <li>An open in the wire</li> </ul>
4	GRN/BLU²	Driver's door open	Check for voltage to ground: There should be 1 V or less.	<ul style="list-style-type: none"> <li>Faulty door switch</li> <li>Poor ground (G401, G402, G403)</li> <li>An open in the wire</li> </ul>
5	GRN/RED	Passenger's door open		
6	A14	Connect the A9 terminal to the A14 terminal.	Check window operation: The power windows should work with the key OFF.	<ul style="list-style-type: none"> <li>Faulty power window relay</li> <li>Poor ground (G201)</li> <li>An open in the wire</li> </ul>



**Combined Operation Wiper/Washer System:**

No.	Terminal	Test condition	Test: Desired result	Possible cause if result is not obtained
1	A8	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"><li>• Poor ground (G401, G402, G403)</li><li>• An open in the wire</li></ul>
2	A9	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"><li>• Blown No. 34 (15 A) fuse</li><li>• An open in the wire</li></ul>
3	A5	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"><li>• Blown No. 5 (15 A) fuse</li><li>• An open in the wire</li></ul>
4	BLU/RED	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"><li>• Blown No. 26 (40 A) fuse</li><li>• Faulty wiper intermittent relay</li><li>• An open in the wire</li></ul>
5	YEL	Ignition switch ON (II) and wiper switch at INT position	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"><li>• Blown No. 6 (7.5 A) fuse</li><li>• Faulty wiper switch</li><li>• An open in the wire</li></ul>
6	A4	Ignition switch ON (II) and washer switch pushed	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"><li>• Blown No. 6 (7.5 A) fuse</li><li>• Faulty washer switch</li><li>• An open in the wire</li></ul>
7	A1 and A2	Intermittent dwell time control ring turned	Check for resistance between the A1 and A2 terminals: It should vary from 0 to 28,000 ohms as the ring is turned.	<ul style="list-style-type: none"><li>• Faulty intermittent dwell time con- troller</li><li>• An open in the wire</li></ul>
8	A7	Ignition switch ON (II) and wiper switch OFF	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"><li>• Blown No. 26 (40 A) fuse</li><li>• Faulty wiper motor (automatic- stop circuit)</li><li>• An open in the wire</li></ul>