




# Security Alarm System

## Control Unit Input Test

Remove the glove box, and disconnect the 22-P connector and 16-P connector from the control unit.

Inspect the connector and socket terminals to be sure they are all making good contact.

- If the terminals are bent, loose, or corroded, repair them as necessary, and recheck the system.
- If the terminals look OK, make the following input tests at the connector.
  - If any test indicates a problem, find and correct the cause, then recheck the system.
  - If all the input tests prove OK, the control unit must be faulty; replace it.
- Different wires with the same color have been given a number suffix to distinguish them (for example, YEL/GRN<sup>1</sup> and YEL/GRN<sup>2</sup> are not the same).



View from wire side

No.	Wire	Test condition	Test: Desired result	Possible cause if result is not obtained
1	BLK	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
2	WHT/GRN	Under all conditions	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 18 (20 A) fuse</li> <li>• An open in the wire</li> </ul>
3	GRN	Under all conditions	Connect to ground: The security indicator should come on.	<ul style="list-style-type: none"> <li>• Blown No. 45 (20 A) fuse</li> <li>• Faulty security indicator</li> <li>• An open in the wire</li> </ul>
4	YEL	Ignition switch ON (II)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Blown No. 5 (15 A) fuse</li> <li>• An open in the wire</li> </ul>
5	BLK/GRN	Ignition switch START (III)	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Faulty starter cut relay</li> <li>• An open in the wire</li> </ul>
6	BLK/YEL	Ignition switch START (III), clutch pedal pushed (M/T), shift lever in <b>P</b> (A/T)	Attach to ground: The starter should crank the engine.	<ul style="list-style-type: none"> <li>• Blown No. 29 (50 A) fuse</li> <li>• Faulty starting system</li> <li>• Faulty starter cut relay</li> <li>• Faulty clutch interlock switch (M/T)</li> <li>• Faulty A/T gear position switch (A/T)</li> <li>• An open in the wire</li> </ul>




No.	Wire	Test condition	Test: Desired result	Possible cause if result is not obtained
7	LT GRN/ WHT	Under all conditions	Attach to ground: All horns should sound.	<ul style="list-style-type: none"> <li>• Blown No. 45 (20 A) fuse</li> <li>• Faulty horn relay</li> <li>• Faulty horn (either)</li> <li>• Poor ground (G301 or G302)</li> <li>• An open in the wire</li> </ul>
8	BLU/RED	Under all conditions	Attach to ground: The headlights should come on.	<ul style="list-style-type: none"> <li>• Faulty headlight relay</li> <li>• Faulty headlight system</li> <li>• An open in the wire</li> </ul>
9	RED/YEL	Under all conditions	Connect to ground: The taillights should come on.	<ul style="list-style-type: none"> <li>• Faulty taillight relay</li> <li>• Faulty taillight system</li> <li>• An open in the wire</li> </ul>
10	LT GRN/ RED	Passing switch ON	Check for voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> <li>• Faulty passing switch</li> <li>• Faulty dimmer relay</li> <li>• Faulty headlight relay</li> <li>• An open in the wire</li> </ul>
11	YEL/GRN <sup>2</sup>	Hood open	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Faulty hood switch</li> <li>• Misadjusted hood switch</li> <li>• Poor ground (G301)</li> <li>• An open in the wire</li> </ul>
		Hood closed	Check for continuity to ground: There should be no continuity.	
12	BLU/GRN	Ignition key is in the ignition switch.	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Faulty ignition key switch</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
		Ignition key is not in the ignition switch.	Check for continuity to ground: There should be no continuity.	
13	BLU	Engine compartment lid open	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Faulty engine compartment lid switch</li> <li>• Misadjusted engine compartment lid switch</li> <li>• Poor ground (G401, G402, G403)</li> <li>• An open in the wire</li> </ul>
		Engine compartment lid closed	Check for continuity to ground: There should be no continuity.	
14	BLK/BRN or BLK/ LT GRN	Under all conditions	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Poor ground (G404)</li> <li>• An open in the wire</li> </ul>
15	BRN/WHT	Trunk key in UNLOCK	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Faulty trunk key</li> <li>• Poor ground (G551)</li> <li>• An open in the wire</li> </ul>
16	WHT	Trunk lid open	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>• Faulty trunk latch switch</li> <li>• Misadjusted trunk latch switch</li> <li>• Poor ground (G551)</li> <li>• An open in the wire</li> </ul>
		Trunk lid closed	Check for continuity to ground: There should be no continuity.	

(cont'd)

# Security Alarm System

## Control Unit Input Test (cont'd)



\*: Not used

No.	Wire	Test condition	Test: Desired result	Possible cause if result is not obtained
17	GRN/BLU	Driver's door open	Check for continuity to ground: When the door is open, there should be continuity. When the door is closed, there should be no continuity.	<ul style="list-style-type: none"> <li>Faulty right door switch</li> <li>An open in the wire</li> </ul>
		Driver's door closed		
18	GRN/RED	Passenger's door open		
		Passenger's door closed		
19	GRN/YEL <sup>1</sup>	Driver's door key in UNLOCK	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>Faulty left or right door key switch</li> <li>Poor ground (G401, G402, G403)</li> <li>An open in the wire</li> </ul>
20	GRN/YEL <sup>2</sup>	Passenger's door key in UNLOCK		
21	GRN/WHT	Driver's door key in LOCK	Check for continuity to ground: There should be continuity, as the door keylock is turned to LOCK.	<ul style="list-style-type: none"> <li>Faulty left or right door key switch</li> <li>Poor ground (G401, G402, G403)</li> <li>An open in the wire</li> </ul>
22	GRY/WHT	Passenger's door key in LOCK		
23	BLU/RED <sup>2</sup>	Driver's door lock knob in UNLOCK	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>Faulty left door lock knob switch (Built into the actuator)</li> <li>Poor ground (G401, G402, G403)</li> <li>An open in the wire</li> </ul>
24	BLU/RED <sup>3</sup>	Passenger's door lock knob in UNLOCK	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>Faulty right door lock knob switch (Built into the actuator)</li> <li>Poor ground (G401, G402, G403)</li> <li>An open in the wire</li> </ul>
25	RED/GRN <sup>*1</sup>	Roof unlatched	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> <li>Faulty right or left roof lock switch</li> <li>Poor ground (G401, G402, G403)</li> <li>An open in the wire</li> </ul>
26	RED/YEL <sup>*1</sup>			

\*1: NSX-T (open top)