Construction

Features

The reinforced parts are located as shown.

�earthquake : Reinforced parts.

ROOF PANEL

TRUNK FRONT
CROSS MEMBER

DASHBOARD
UPPER CROSS
MEMBER

FLOOR CROSS
MEMBER
BULKHEAD

CENTER PILLAR
UPPER
REINFORCEMENT

CENTER PILLAR
LOWER REINFORCEMENT

UPPER
STIFFENER

SIDE SILL
STIFFENER

LOWER STIFFENER

FRONT SIDE
SILL EXTENSION

LOWER
REINFORCEMENT

Upper
Reinforcement
Upper stiffener

Inner pillar

Upper patch
Outer panel

Front Pillar Section

20-78