

# Brakes

## Conventional Brake System

Special Tools .....	19-2
Component Location Index .....	19-3
Pedal Height Adjustment .....	19-4
Parking Break Adjustment .....	19-4
Front Brakes	
Index/Inspection .....	19-5
Front Brake Pads	
Inspection/Replacement ...	19-6
Front Caliper	
Disassembly .....	19-8
Reassembly .....	19-9

## Anti-lock Brake System (ABS)

Features/Construction/ Operation .....	19-28
Wiring/Connector Locations ...	19-40
ALB Checker	
Function Test .....	19-41
Wheel Sensor Signal Confirmation .....	19-43
Troubleshooting	
Anti-lock Brake System (ABS) Indicator Light	
'91-'92 Models .....	19-44
'93-'96 Models .....	19-44

## Traction Control System (TCS)

Special Tools .....	19-74
Component Locations	
'91-'94 Models .....	19-74
'95-'96 Models .....	19-75b
System Description	
Outline .....	19-76
Construction and Function	
'91-'94 Models .....	19-76
'95-'96 Models .....	19-77

Front Brake Disc	
Runout Inspection .....	19-9
Thickness and Parallelism Inspection .....	19-10
Bleeding .....	19-10
Master Cylinder and Brake Booster	
Index/Torque .....	19-12
Master Cylinder Inspection .....	19-13
Brake Booster Tests .....	19-14

Symptom-to-System Chart .....	19-46
Hydraulic System	
Hydraulic Connections	
'91-'92 Models .....	19-61
'93-'96 Models .....	19-61
Relieving Accumulator/ Line Pressure	
'91-'92 Models .....	19-62
'93-'96 Models .....	19-62
Modulator/Solenoid Unit	
Index/Torque	
'91-'92 Models .....	19-63
'93-'96 Models .....	19-63

TCS Control Unit	
Terminal Arrangement	
'95-'96 Models .....	19-82
Troubleshooting	
TCS Indicator Light	
'91-'94 Models .....	19-82
'95-'96 Models .....	19-84
Troubleshooting Guide	
'91-'94 Models .....	19-84
'95-'96 Models .....	19-86

Pushrod Clearance Adjustment .....	19-15
Rear Brakes	
Torque/Inspection .....	19-16
Rear Brake Pads	
Inspection/Replacement ...	19-17
Rear Brake Disc	
Runout Inspection .....	19-19
Thickness and Parallelism Inspection .....	19-20

Solenoid Leak Test	
'91-'92 Models .....	19-64
'93-'96 Models .....	19-64
Solenoid Flushing	
'91-'92 Models .....	19-65
'93-'96 Models .....	19-65
Power Unit	
Torque/Inspection .....	19-66
Accumulator/Pressure Switch	
Index/Torque .....	19-67
Removal .....	19-68
Accumulator Disposal .....	19-68
Bleeding	
Air Bleeding with ALB	

Electronic Components	
TCS Switch Inspection	
'91-'94 Models .....	19-137
'95-'96 Models .....	19-107
TCS Fail-safe Replay Test .....	19-137
Lateral Acceleration (Lg) Sensor Inspection	
'95-'96 Models .....	19-107

Rear Caliper	
Disassembly .....	19-20
Reassembly .....	19-23
Brake Hoses/Pipes	
Inspection .....	19-26
Parking Brake	
Disassembly/ Reassembly .....	19-27

Checker	
'91-'92 Models .....	19-69
'93-'96 Models .....	19-69
ABS Control Unit	
Replacement .....	19-70
Fail-Safe Relays/Motor Relay Inspection .....	19-71
Pulsers/Sensors	
Inspection .....	19-71
Front Sensor Replacement .....	19-72
Rear Sensor Replacement .....	19-72

Steering Angle Sensor	
Replacement	
'91-'94 Models .....	19-138
'95-'96 Models .....	19-108
TCS Control Unit	
Replacement	
'95-'96 Models .....	19-110