

HVAC (Heating, Ventilation and Air Conditioning)

*: Read [SRS precautions](#) before working in this area

Special Tools			
'91-'94 Models	22-2		
'95-'96 Models	22-2		
Component Location			
Index	22-3		
Heater-Evaporator Door			
Position	22-4		
Description			
Outline	22-6		
A/C Triple Pressure			
Switch	22-7		
Fan Control Unit	22-8		
Wiring/Connector			
Locations	22-9		
Troubleshooting			
Self-diagnosis Circuit			
Check	22-12		
Function Selection and			
Operation Check	22-13		
Symptom-to-Component			
Chart	22-14		
Climate Control Unit			
Input/Output Signals ...	22-15		
		Climate Control Unit	
		Replacement	22-54
		Adjustment	22-55
		Air Mix Control Motor	
		Replacement	22-56
		Test	22-57
		Mode Control Motor	
		Replacement	22-57
		Test	22-58
		Recirculation Control Motor	
		Test	22-59
		Replacement	22-59
		Vent Door Control Motor	
		Test	22-60
		Replacement	22-60
		In-car Temperature Sensor	
		Replacement	22-61
		Test	22-61
		Outside Air Temperature Sensor	
		Replacement	22-62
		Test	22-62
		Sunlight Sensor	
		Removal	22-63
		Test	22-63
		Heater Core Temperature Sensor	
		Removal	22-64
		Test	22-64
		Evaporator Temperature Sensor	
		Removal	22-65
		Test	22-65
		Aspirator Fan Test	22-66
		Relay Test	22-66
		Blower Unit	
		Replacement	22-67
		Overhaul	22-68
		A/C Service Tips	
		and Precautions	22-69
		A/C System Service	
		Performance Test	22-70
		Pressure Test Chart	22-72
		Refrigerant Recovery	22-73
		Evacuation	22-89
		Leak Test	22-90
		Charging	22-91
		Heater-Evaporator Unit	
		Replacement	22-74
		Overhaul	22-76
		"DEF" Door Adjustment ...	22-77
		"HEAT" Door Adjustment ..	22-77
		Condenser	
		Description	22-78
		Replacement	22-79
		Overhaul	22-80
		Compressor	
		Description	22-81
		Component Location	
		Index	
		'91-'92 Models	22-76
		'93-'96 Models	22-82
		Replacement	22-83
		Clutch Inspection	22-85
		Clutch Overhaul	22-86
		Relief Valve	
		Replacement	22-87
		Belt Adjustment	22-88