

Engine Electrical

Starting System

Component Location Index	23-75
Description	23-76
Starter Test	23-78
Starter Cut Relay Test	23-80
Clutch Interlock Switch Test (M/T)	23-80
Starter Solenoid Test	23-81
Starter	
Replacement	23-81
Overhaul	23-82
Starter Brush Holder Test	23-83
Starter Brush Inspection	23-83
Armature Inspection and Test	23-84
Solenoid Plunger Inspection	23-86
Starter Field Winding Test	23-86
Overrunning Clutch Inspection	23-87
Starter Reassembly	23-87
Ignition System	
Component Location Index	
'91-'92 Models	23-88
'93-'96 Models	23-88
Description	23-89
Ignition Timing Inspection	
'91-'94 Models	23-91
'95-'96 Models	23-91
Idle Speed Inspection	23-92

Ignition Control Module (ICM)

Replacement	23-92
Input Test	23-93
Ignition Coil/Spark Plugs	
Removal	
'91-'94 Models	23-94
'95-'96 Models	23-94
Ignition Coil Test	
'91-'94 Models	23-95
'95-'96 Models	23-95
Spark Plug Inspection	23-96
Noise Condenser Capacity Test	23-97
Charging System	
Component Location Index	23-98
Troubleshooting	
Charging System Light	23-100
Alternator/Regulator Test	23-102
Alternator	
Replacement	23-105
Overhaul	
'91-'94 Models	23-106
'95-'96 Models	23-106
Rectifier Test	23-107
Alternator Brush Inspection	23-107
Rotor Slip Ring Test	23-108
Stator Test	23-108
Alternator Belt Adjustment	23-109

Radiator and Condenser Fan

Controls	
Component Location Index	
'91-'94 Models	23-110
'95-'96 Models	23-110
Description	
'91-'92 Models	23-112
'93-'96 Models	23-114
Troubleshooting	
'91-'92 Models	23-113
'93-'94 Models	23-115
'95-'96 Models	23-115
Control Unit Terminals	23-116
Radiator Fan Resistor Test	23-116
Radiator Fan Motor Test	23-117
Condenser Fan Motor Test	23-117
Engine Compartment Fan Motor (A/T)	
Test	23-118
Removal	23-118
Fan Relay Tests	23-119
Radiator Fan Control Sensor	
Test	23-120
Cruise Control	
Component Location Index	
'91-'92 Models	23-286
'93-'94 Models	23-290
'95-'96 Models	23-298
Description	
'91-'94 Models	23-292
'95-'96 Models	23-300

Troubleshooting

'91-'92 Models	23-291
'93-'94 Models	23-295
'95-'96 Models	23-302
Control Unit Input Test	
'91-'92 Models	23-292
'93-'94 Models	23-296
'95-'96 Models	23-303
Main Switch	
Replacement	
'91-'92 Models	23-294
'93-'94 Models	23-298
'95-'96 Models	23-305
Test	
'91-'92 Models	23-295
'93-'94 Models	23-299
'95-'96 Models	23-306
Set/Resume Switch Test	23-307
Brake Switch Test	23-308
Clutch Switch Test	23-308
A/T Gear Position Switch	
Test	23-309
Cruise Control Actuator	
Assembly Test	
'91-'94 Models	23-302
Cruise Control Actuator	
Cable Adjustment	
'91-'94 Models	23-303