## **Change Holder Assembly**



## -Disassembly/Reassembly -

NOTE: Make sure the return springs are installed properly.



Prior to reassembling, clean all parts in solvent, dry them, and apply lubricant to any contact surfaces.

