

Power Unit

Torque/Inspection

CAUTION:

- Do not attempt to disassemble the power unit except for those components shown in this illustration.
- Do not spill brake fluid on the car; if brake fluid does contact the paint, wash it off immediately with water.
- To prevent spills, cover the hose joints with rags or shop towels.
- Clean all parts in brake fluid and air dry; blow out all passages with compressed air.

- Before reassembling, check that all parts are free of dust and other foreign particles.
- Replace parts with new ones whenever specified to do so.
- Make sure no dirt or other foreign matter is allowed to contaminate the brake fluid.
- Do not reuse the drained fluid.
Use only clean DOT 3 or 4 brake fluid.

