


Aspirator Fan

Test

Connect battery power to the No. 3 terminal of the aspirator fan, and connect ground to the No. 4 terminal. The aspirator fan should run.



Relay

Test

There should be continuity between the C and D terminals.

There should be continuity between the A and B terminals when power and ground are connected to the C and D terminals.

There should be no continuity when power is disconnected.

