




## Hazard Warning Switch Test


1. Remove the dashboard lower cover (see page 23-220).
2. Disconnect the 20-P connector from the floor wire harness.
3. Check for continuity between the terminals, in each switch position, according to the table.

Terminal	F		D	E	N	G		H
Position								
OFF								
ON								

HAZARD WARNING SWITCH



20-P CONNECTOR



View from wire side

Terminal N is not used.

