


Horns

Component Location Index

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section \(24\)](#) before performing repairs or service.



Description

Security Alarm System:

The security alarm system is an anti-theft alarm system. If someone tries to open the trunk, hood or either door without the ignition key, or if the roof is not fully latched the security control unit senses a signal from the sensors and activates relays to flash the headlights and sound the horn for about two minutes.