






Component Locations

Index



PGM-FI MAIN RELAY
Relay Testing, page 11-120
Troubleshooting, page 11-122





SERVICE CHECK CONNECTOR (2P)
Self-diagnostic Procedures, page 11-34

ENGINE CONTROL MODULE (ECM)
Self-diagnostic Procedures, page 11-34
Troubleshooting, page 11-42

Component Locations

Index



FUEL PUMP RELAY
Troubleshooting, page 11-116

