

Emission Control System



System Troubleshooting Guide

NOTE: Across each row in the chart, the sub-systems that could be sources of a symptom are ranked in the order they should be inspected starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next most likely system ②, etc.

PAGE		SUB-SYSTEM	THREE WAY CATALYTIC CONVERTER	EXHAUST GAS RECIRCULATION SYSTEM	POSITIVE CRANKCASE VENTILATION SYSTEM	EVAPORATIVE EMISSION CONTROLS
SYMPTOM			143	145	151	152
ROUGH IDLE				①	②	
FREQUENT STALLING	AFTER WARMING UP			①		
POOR PERFORMANCE	FAILS EMISSION TEST		①	③		②
	LOSS OF POWER		①	②		