

Emission Control System

Three Way Catalytic Converter (cont'd)

Inspection

If excessive exhaust system back-pressure is suspected, remove the three way catalytic converter from the car and make a visual check for plugging, melting or cracking of the catalyst. Replace the three way catalytic converter if any of the visible area is damaged or plugged.

